



AMI Marine (UK) Ltd

## Bridge Navigational Watch Alarm System KW810 BNWAS

### PRICE LIST

AMI BNWAS carries full Type Approval according to International Standard IEC 62616

	Product Code	Product	Description	Prices £ (GBP)
	KW810-MAP	Monitor and Alert Panel (including MEU and Alarm Interface)	<p><b>Monitor &amp; Alert Panel (M).</b> The Monitor and Alarm Panel is situated on the bridge and gives an audible and visual alarm for Stage 1 Alert. The MAP also has an emergency call function that can be used to raise a response from the ship's officers if required.</p> <p><b>Main Electronics Unit (MEU).</b> The KW810 MEU is housed in a rugged IP57 enclosure. There are 4 inputs providing connection to Autopilot, GPS and Unacknowledged Alarms. An output is also provided for VDR/S-VDR recording. Extra interfacing has been provided in order to accommodate future IMO requirements.</p>	850
	KW810-W	Watch Alert Panel	<p><b>Watch Alert panel (WAP).</b> The WAP provides a visual and audible alarm for stages 2 &amp; 3. This unit is perfect for officer cabins and crew common areas such as ships office, mess, smoke room etc.</p>	120
	KW810-R	Remote Alert Panel	<p><b>Remote Alert Panel (RAP).</b> The Remote Alert Panel is a reset button that can be installed at various points throughout the bridge. Due to the RAP being based in an IP65 enclosure this unit can also be fitted outside on the bridge wing.</p>	140
	KW810-P	Passive Infrared Detector (Motion Sensor).	<p><b>Passive Infrared Detector (PIR)</b> The Passive infrared Detector has a range of 12metres through a 90° arc. It can detect human presence and helps to reduce the need to operate the reset button when the crew are busy on the bridge. This item is subject to class approval.</p>	65
	KW810-DOS	Duty officer Selector	<p><b>Duty Officer Selector (DOS).</b> The Duty Officer Selector switch is used to direct stage 2 alarms to the appropriate on duty officer's cabin. This is useful for preventing the off duty officers from being interrupted while resting.</p>	180
	KW810-SAB	Sounder Alarm Beacon	<p><b>Sounder Alarm Beacon (SAB).</b> The Sounder Alarm Beacon gives an audible and visual indicator of stage 2 and 3 alarms. This unit is ideal for officer cabins, crew common areas and is especially suited to large noisy areas within the vessel. This unit comes with a programmable volume and type approved tone.</p>	115

Prices valid from 1<sup>st</sup> May 2012  
All prices in £ GBP, Ex-Works Southampton UK.  
Taxes not included

E&OE  
Warranty: 36 Months – 1<sup>st</sup> 12 Months = Parts & Labour, 2<sup>nd</sup> & 3<sup>rd</sup> = Parts only.  
Terms & Conditions apply.

For further information on our range of products or to request a quotation please contact us on  
Tel: +44 (0) 2380 480450 Fax: +44 (0) 2380 480451 Email: [sales@amimarine.net](mailto:sales@amimarine.net) Web: [www.amimarine.net](http://www.amimarine.net)